

USER MANUAL

HTR02 series

Heater for calibration and verification of performance of FHF-type heat flux sensors




Warning statements

Cautionary statements are subdivided into four categories: danger, warning, caution and notice according to the severity of the risk.

 DANGER
Failure to comply with a danger statement will lead to death or serious physical injuries.

 WARNING
Failure to comply with a warning statement may lead to risk of death or serious physical injuries.

 CAUTION
Failure to comply with a caution statement may lead to risk of minor or moderate physical injuries.

NOTICE
Failure to comply with a notice may lead to damage to equipment or may compromise reliable operation of the instrument.

Contents

Warning statements	2
Contents	3
List of symbols	4
Introduction	5
1 Ordering and checking at delivery	7
1.1 Ordering HTR02	7
1.2 Included items	7
1.3 Quick instrument check	8
2 Instrument principle and theory	9
2.1 Basic operation	9
2.2 A self-test for heat flux sensors	9
2.3 Using heaters with FHF05 series	10
2.4 Calibrating heat flux sensors	12
2.5 An in-situ test for heat flux sensors	13
3 Specifications of HTR02 series	16
3.1 Specifications of HTR02 series	16
3.2 Dimensions of HTR02 series	18
4 Installation of HTR02 series	19
4.1 Site selection and installation	19
4.2 Electrical connection	21
5 Maintenance and trouble shooting	23
5.1 Recommended maintenance and quality assurance	23
5.2 Trouble shooting	24
5.3 Calibration and checks in the field	24
6 Appendices	25
6.1 EU declaration of conformity	25

List of symbols

Quantities

Heat flux
Voltage
Sensitivity
Temperature
Thermal resistance per unit area
Area
Electrical resistance
Electrical power

Symbol

Unit

Φ W/m²
U V
S V/(W/m²)
T °C
R_{thermal,A} K/(W/m²)
A m²
R Ω
P W

Subscripts

Property of heatsink
Property of heater
Property of sensor
Maximum value, specification limit

heatsink
heater
sensor
maximum

Introduction

HTR02 series are heaters that can be used for calibration and functionality checks of FHF-type heat flux sensors like FHF05 series. The heaters have a 4-wire connection with a known surface area and electrical resistance. Users can now easily and objectively check their sensor performance before and after use. HTR02 series is available in two different models: 50 x 50 and 85 x 85 mm. See also **FHF05SC series** heat flux sensor with integrated heater.

Measuring heat flux, users may wish to regularly check their sensor performance. A quick check or a formal calibration is now possible with HTR02 series plus some accessories that most laboratories will have in-house. The HTR02 series heaters have a well characterised traceable surface area and electrical resistance.

In a typical test setup, the heat losses through the insulation are typically smaller than 3 % and may be ignored. Measuring the heater power (voltage U_{heater} squared divided by resistance R_{heater}), and dividing by the surface area A_{heater} , gives the applied heat flux. The heat flux sensor sensitivity S is the voltage output U_{sensor} divided by the applied heat flux.

$$S = (U_{\text{sensor}} \cdot R_{\text{heater}} \cdot A_{\text{heater}}) / U_{\text{heater}}^2 \quad (\text{Formula 0.1})$$

The reproducibility of this test is much improved when using contact material between heater, sensor and heat sink.

HTR02 series has unique features and benefits:

- makes it possible to perform a simple test
- guarantees sensor stability
- matches FHF05 series heat flux sensors




Figure 0.1 On the left model HTR02-85X85 heater for calibration and verification of performance of the models of FHF05 series heat flux sensors, on the right model FHF05-85X85 to which HTR02-85X85 may be applied. See also figure 3.2.1 for dimensions.

HTR02 series is a foil heater and comes in two models. Either it can be used in combination with foil heat flux sensors such as FHF05 series for test and calibration purposes, or it can be used as a general-purpose heater.

Options:

- available with standard cable length -02 metre, or change -02 to -05 or -10 metres for the respective cable length
- cables can also be ordered separately in 2, 5 or 10 metres length

See also:

- [FHF05SC](#) heat flux sensor with integrated heater
- [FHF05 series](#) general purpose heat flux sensor
- view our complete range of [heat flux sensors](#)

1 Ordering and checking at delivery

1.1 Ordering HTR02

The standard configuration of HTR02 series is model 50X50 with 2 metres of cable, order code: HTR02-50X50-02.

Common options are:

- model HTR02-85X85
- -05 or -10 metres cable length
- with a separate cable in 2, 5 or 10 metres cable length

1.2 Included items

Arriving at the customer, the delivery should include:

- HTR02 heater with cable of the length as ordered
- product certificate matching the instrument serial number




Figure 1.2.1 Model HTR02-50X50 with serial number and resistance shown at the end of the cable.

1.3 Quick instrument check

A quick test of the instrument can be done by connecting it to a multimeter:

1. Check the heater serial number on the label at the end of HTR02's cable against the product certificate provided with the heater.
2. Inspect the instrument for any damage.
3. Check the electrical resistance of the heater between any of the yellow wires and any of the grey wires. Use a multimeter at the 1 k Ω range. Typical resistance should be around 120 Ω for model -50X50 and around 40 Ω for model -85X85. Infinite resistance indicates a broken circuit; zero or a lower than 1 Ω resistance indicates a short circuit.
4. Check the electrical resistance between the 2 yellow wires. These resistances should be in the 0.1 Ω /m range, so 0.2 Ω in case of the standard 2 m wire length. Higher resistances indicate a broken circuit. Repeat this measurement for the 3 grey wires.

2 Instrument principle and theory

HTR02 series is a foil heater. Either it can be used in combination with foil heat flux sensors such as FHF05 series for test and calibration purposes, or it can be used as a general-purpose heater.

2.1 Basic operation

If a voltage U_{heater} is applied to the heater such that an electrical current I_{heater} runs through the heater, the heater power P_{heater} may be calculated as:

$$P_{\text{heater}} = U_{\text{heater}} \cdot I_{\text{heater}} = U_{\text{heater}}^2 / R_{\text{heater}} = I_{\text{heater}}^2 \cdot R_{\text{heater}}$$

where R_{heater} is the heater electrical resistance. If the heater is placed in a uniform environment (i.e., same medium on both sides of the heater) the applied heat flux Φ in either direction may be calculated as:

$$\Phi = P_{\text{heater}} / (2 \cdot A_{\text{heater}}) \quad (\text{Formula 2.1.1})$$

where A_{heater} is the heater area. If, however, the heater is placed in between a thermal insulator and a good thermal conductor the heat flux Φ in the direction of the conductor is:

$$\Phi = P_{\text{heater}} / A_{\text{heater}} \quad (\text{Formula 2.1.2})$$

Other cases exist as well. Users need to evaluate which case applies to their situation.

2.2 A self-test for heat flux sensors

In combination with a heat flux sensor such as FHF05 series, HTR02 can be used to test the response of the heat flux sensor. To this end HTR02 should be positioned directly on top of the heat flux sensor such that HTR02 can be used to apply a heat flux through the heat flux sensor.

A self-test is started by switching on HTR02, while recording the heat flux sensor output signal and the HTR02 heater power and finalised by switching HTR02 off. During the heating interval, I_{heater} is fed through the foil heater which generates a heat flux proportional to the heater power. P_{heater} can be measured in several different ways:

- heater voltage and current, $P_{\text{heater}} = U_{\text{heater}} \cdot I_{\text{heater}}$ (Formula 2.2.1)
- heater voltage and known heater resistance, $P_{\text{heater}} = U_{\text{heater}}^2 / R_{\text{heater}}$ (Formula 2.2.2)
- heater current and known heater resistance, $P_{\text{heater}} = I_{\text{heater}}^2 \cdot R_{\text{heater}}$ (Formula 2.2.3)

If performed in a four-wire configuration the first method is preferred because it is generally more accurate than the latter two methods, however it requires both a voltmeter and an ammeter instead of just one of the two.

Analysis of the heat flux sensor response to the heating (the self-test) serves several purposes:

- first, the amplitude and response time under comparable conditions are indicators of the sensor stability. See 2.5 for application examples.
 - second, the functionality of the complete measuring system is verified. For example: a broken cable is immediately detected.
 - third, under the right conditions, after taking the sensor out of its normal environment, the self-test may be used as calibration. See 2.4 for more details.
- Compatible compatible

2.3 Using heaters with FHF05 series

HTR02 series is compatible with the models from the FHF05 series. Model FHF05-50X50 and -85X85 fit directly with HTR02-50X50 and -85X85 respectively.

Models FHF05-10X10 and FHF05-15X30 fit with HTR02-50X50. Model FHF05-15X85 can be used with HTR02-85X85. Because in these cases the heater is larger than the sensor, it is recommended to make a guard when using these models with HTR02. See table 2.3.1 for an overview of the models and suggested heaters.




Figure 2.3.1 Using heater model HTR02-50X50 with heat flux sensor FHF05-15X30. A plastic guard is made with help of a 3D-printer.

To get a representative measurement, the heater should 'see' the same environment. Surrounded by a material like a metal heat sink, the sensor will locally increase the thermal resistance. The heat from the heater will follow the easiest path; in the case the heater is larger than the sensor, flow to the metal heat sink. Therefore, the sensor will measure an underestimation of the actual heat flux.




Figure 2.3.2 Using HTR02 series heaters with FHF05 series. FHF05 models -10X10 and -15X30 are compatible with HTR02-50X50. Model FHF05-15X85 is compatible with HTR02-85X85. We recommend making a guard around the sensor with equal thermal resistance and thickness. The orange-coloured part is the area where we recommend making a guard.

To create an environment with constant thermal resistance, make a guard around the sensor with equal thermal resistance and thickness. FHF05 series have a thermal resistance of $R_{\text{thermal}} = 11 \times 10^{-4} \text{ K}/(\text{W}/\text{m}^2)$ and a thickness of $0.4 \times 10^{-3} \text{ m}$.

We recommend a guard made from plastic. Most plastics have a thermal resistance in the same order of magnitude as the base material of the sensor. Use tape of comparable thickness or print a guard with a 3D printer. See figure 2.3.1.

Table 2.3.1 Suggested use of FHF05 series with HTR02 series.

MODEL FHF05	SUGGESTED HTR02 MODEL	GUARD RECOMMENDED?
FHF05-10X10	HTR02-50X50	yes
FHF05-15X30	HTR02-50X50	yes
FHF05-50X50	HTR02-50X50	no
FHF05-15X85	HTR02-85X85	yes
FHF05-85X85	HTR02-85X85	no

2.4 Calibrating heat flux sensors

It is recommended to recalibrate heat flux sensors at least once every two years. HTR02 series can be used to calibrate heat flux sensors such as the models in the FHF05 series. In a typical calibration setup as shown in figure 2.4.1, a stack is made of a heatsink, the heat flux sensor to be calibrated, the heater and an insulating material. In such a setup, the heat losses through the insulation is for FHF-type sensors in the order of magnitude of 3 %. In this case heat generated by HTR02 flows through the heat flux sensor to the heat sink. Measuring the heater power P_{heater} , and dividing by the surface area A_{heater} , gives the applied heat flux:

$$\Phi = P_{\text{heater}}/A_{\text{heater}} \quad (\text{Formula 2.3.1})$$

The heat flux sensor sensitivity S is the voltage output of the sensor U_{sensor} divided by the applied heat flux Φ :

$$S = U_{\text{sensor}}/\Phi \quad (\text{Formula 2.3.2})$$

The reproducibility of this test is much improved when using contact material (such as glycerol or a thermal paste) between heater, sensor and heat sink.




Figure 2.4.1 Calibration of a heat flux sensor; a typical stack used for calibration consists of a block of metal (mass > 1 kg), for example aluminium (5), the heat flux sensor (3), HTR02 (2) and an insulation foam (1). Under these conditions, heat losses through the insulation are negligible. Heat flux (4) flows from hot to cold.

2.5 An in-situ test for heat flux sensors

The HTR02 series heater can be used to test the stable performance of the heat flux sensors such as FHF05 series.

HTR02 series should be installed on top of the heat flux sensor, preferably on the side of the heat flux sensors with the more insulating medium. In case the heater is used for repeated verifications at one location, consider using our FHF05SC series: sensor with a HTR02 heater integrated.

A typical stability check is performed based on the step response of the measured heat flux and sensor temperature to a heat flux applied by HTR02. Upon installing the heat flux sensor and HTR02, a reference measurement should be made. A time trace of the heater power, the measured heat flux and the measured sensor temperature should be stored as reference data. Stable operation of the heat flux sensor can then be confirmed at any time by comparing to the reference measurement. The test protocol consists of the following steps:

1. Make sure that the absolute temperature is similar to that during the reference measurement.
2. Check the heater resistance stability. This can be done accurately by using the four heater wires to conduct a four-point resistance measurement.
3. Record a time trace of the heater power, the measured heat flux and the sensor temperature; the same parameters as in the reference data. Normalise the data by the heater power. Under normal circumstances (if the heater is stable) this process scales with U_{heater}^2 .
4. Compare patterns of heat flux and temperature rise and fall. In both cases relative to the values just before heating.
 - When the signal patterns match, amplitude differences, after correction for heater power, point towards sensor instability. In this case recalibration of the sensor may be required (Figure 2.5.1).
 - Non-matching patterns point towards changes in sensor environment. This can for example be the result of a loss of thermal contact between sensor and object (Figure 2.5.2) or the presence of convective heat losses (Figure 2.5.3).




Figure 2.5.1 *In-situ sensor stability check. Comparison of responses to stepwise heating relative to reference curves. Normalised to heater power (P) and relative to the heat flux and the temperature just before heating. Solid graphs show heat flux, dotted graphs show temperature. The black HF and T signals are the reference curves at installation. The sensor shows non-stability, loses sensitivity over time, which results in the red responses: equal response times, lower heat flux and equal temperature rise.*




Figure 2.5.2 *In-situ sensor stability check. Comparison of responses to stepwise heating relative to reference curves. Normalised to heater power (P) and relative to the heat flux and the temperature just before heating. Solid graphs show heat flux, dotted graphs show temperature. The black HF and T signals are the reference curves at good thermal contact. The sensor loses thermal contact, which results in the blue responses: slower response times, lower heat flux and higher temperature rise.*




Figure 2.5.3 *In-situ sensor stability check. Comparison of responses to stepwise heating relative to reference curves. Normalised to heater power (P) and relative to the heat flux and the temperature just before heating. Solid graphs show heat flux, dotted graphs show temperature. The black HF and T signals are the reference curves at zero wind speed. The sensor is exposed to convection, which results in the grey responses: faster response times at lower heat flux and lower temperature rise.*

3 Specifications of HTR02 series

3.1 Specifications of HTR02 series

HTR02 series is a heater with 4-wire connection with a known surface area and electrical resistance. It is designed for calibration and functionality checks of FHF-type sensors but can also be used for general heating purposes.

Table 3.1 Specifications of HTR02 series (continued next page).

HTR02 SERIES SPECIFICATIONS	
Product type	foil heater
Measurement function / required programming	depends on the application
Required readout	1 x current channel and 1 x voltage channel, alternatively 1 x current channel or alternatively 1 voltage channel. currents may be measured using a voltage channel which acts as a current measurement channel using a current sensing resistor heater: 1 x switchable 12 VDC
Rated load on the cable	≤ 1.6 kg
Rated bending radius	≥ 7.5 x 10 ⁻³ m
Operating temperature range	-40 to +150 °C
Heater length and width per dimension	
	HTR02-50X50 (48 x 47.6) x 10 ⁻³ m
	HTR02-85X85 (83 x 82.6) x 10 ⁻³ m
Heater area	
	HTR02-50X50 2381 x 10 ⁻⁶ m ²
	HTR02-85X85 7022 x 10 ⁻⁶ m ²
Passive guard area	
	HTR02-50X50 2152 x 10 ⁻⁴ m ²
	HTR02-85X85 3692 x 10 ⁻⁴ m ²
Guard width to thickness ratio	
	HTR02-50X50 6 m/m
	HTR02-85X85 6 m/m
Heater thickness	0.1 x 10 ⁻³ m
Heater thermal resistance	4 x 10 ⁻⁴ K/(W/m ²)
Heater thermal conductivity	0.27 W/(m·K)
Standard cable length	2 m
Heater wiring	4 x copper wire, AWG 28, solid core, bundled with PFA sheath
Wire diameter	1 x 10 ⁻³ m
Marking	1 x label at the end of HTR02's cable, showing serial number and nominal resistance
IP protection class	IP67
Rated operating relative humidity range	0 to 100 %
Gross weight including 2 m wires	approx. 0.5 kg
Net weight including 2 m wires	approx. 0.5 kg
ELECTRICAL CHARACTERISTICS	
Heater resistance (nominal) per dimension (measured value supplied with each sensor in the production report)	
	HTR02-50X50 120 Ω ± 10 %
	HTR02-85X85 40 Ω ± 10 %
Temperature coefficient of resistance	< 0.02 %/°C
Heater rated power supply	24 VDC

Heater power supply	12 VDC (nominal)
Power consumption at 12 VDC per dimension	
	HTR02-50X50 1.20 W
	HTR02-85X85 3.60 W
Nominal heat flux at 12 VDC per dimension	
	HTR02-50X50 500 W/m ²
	HTR02-85X85 500 W/m ²

INSTALLATION AND USE

Recommended number of heaters	one per sensor per measurement location
Installation	see recommendations in this user manual
Wire extension	see chapter on cable extension or order heaters with longer cables

3.2 Dimensions of HTR02 series




Figure 3.2.1 Models HTR02 -50X50 and -85X85; $Y1 = 47.6$ or 82.6 and $Y2=48$ or 83 , dimensions in $\times 10^{-3}$ m

- (1) heater area
- (2) passive guard
- (3) connection block for strain relief
- (4) cable, standard length $C = 2$ m

4 Installation of HTR02 series

4.1 Site selection and installation

Table 4.1.1 Recommendations for installation of HTR02 series.

Surface cleaning and levelling	create a clean and smooth surface of at least the same outer dimensions of the heater: (50 x 50) or (85 x 85) x 10 ⁻³ m
Mounting: avoiding strain on the heater-to-cable transition	the heater-to-cable transition is vulnerable during installation as well as operation, the user should provide proper strain relief of the cable so that the transition is not exposed to significant force first install the cable including strain relief and after that install the heater
Mounting: using a guard	In case the sensor is smaller than the HTR02 heater, a guard is recommended. We suggest making a guard of a material with equal thermal resistance and thickness for best measurement results. See section 2.3.
Mounting: curved surfaces	when mounting HTR02 on curved surfaces, observe the rated bending radius
Mounting: combination with heat flux sensor	when mounting the HTR02 in combination with a heat flux sensor such as the FHF05, keep the directional sensitivity of the heat flux sensor and the position of the heater in mind
Short term installation	avoid any air gaps between heater and surface. Air thermal conductivity is in the 0.02 W/(m·K) range, while a common glue has a thermal conductivity around 0.2 W/(m·K). A 0.1 x 10 ⁻³ m air gap increases the effective thermal resistance of the sensor by 200 % to avoid air gaps, we recommend thermal paste or glycerol for short term installation use tape to fixate the connection block of the heater usually, the cables are provided with an additional strain relief, for example using a cable tie mount as in Figure 4.1.1
Permanent installation	for long-term installation, fill up the space between heater and object with silicone construction sealant, silicone glue or silicone adhesive, that can be bought in construction depots. we discourage the use of thermal paste for permanent installation because it tends to dry out. Silicone glue is more stable and reliable




Figure 4.1.1 *Installation of model HTR02-50X50 using tape to fixate the sensor and the connection block. Extra strain relief of the cable is provided using cable tie mounts equipped with double-sided tape as adhesive. As indicated in Table 4.1.1, tapes fixating the sensor are preferably taped over the passive guard area. In this case, a third tape (in the middle) is added for extra support.*

4.2 Electrical connection

To apply a heat flux, HTR02 should be connected to a power supply. If a variable heat flux is required, the heater can either be connected via a solid-state relay controlled by a pulse-width modulated (PWM) signal or to a programmable power supply (see figure 4.2.1). The HTR02 electrical connections are explained in table 4.2.1. When connecting HTR02, always observe the rated heater voltage. Users must make sure that the used power supply is able to source sufficient current.

Table 4.2.1 *The electrical connections of HTR02. The heater has a cable consisting of four wires. The two yellow wires are equivalent, and the two grey wires are equivalent. Together they serve to make a 4-wire connection to the heater.*

WIRE	HEATER
Yellow	heater power [+]
Yellow	heater measure [+]
Grey	heater power [-]
Grey	heater measure [-]

NOTICE

Putting more than 24 Volt across the sensor wiring can lead to permanent damage to the heater.

The heat generated by HTR02 can be accurately determined by measuring the heater voltage and current in a four-point measurement. To this end HTR02 has a four-wire connection: two yellow wires and two grey wires. A voltmeter should be used to measure the voltage between one of the yellow and one of the grey leads and an ammeter should be used to measure the current through the other yellow and grey leads that are used to apply a voltage to HTR02. See figure 4.2.1

Alternatively, either a measured voltage or a measured current can be combined with a known heater resistance to compute the heat generated by HTR02. Please refer to section 2.1 for more details on how to compute the heater power and applied heat flux.

Suggested HTR02 wiring is shown in figure 4.2.1. The heater serial number and resistance are shown on the HTR02 product certificate and on the label at the end of the cable.

When extending HTR02 cable please consider the thickness and electrical resistance of the wires: too thin wires may lead to excessive heating of the wires themselves.




Figure 4.2.1 Suggested HTR02 heater wiring. Two heater wires are used to carry the heater current; the two others are used to measure the voltage over the heater. There is no significant current flowing through voltage measurement wires so that there is no voltage drop over these wires. This "4-wire connection" measures the true voltage over the heater.

5 Maintenance and trouble shooting

5.1 Recommended maintenance and quality assurance

HTR02 series perform reliably at a low level of maintenance. Unreliable heater output can be detected by scientific judgement, for example by looking for unreasonably large or small measured values. The preferred way to ensure a reliable heater output, is a regular critical review of the measured data.

Table 5.1.1 *Recommended maintenance of HTR02 series. If possible, the data analysis is done daily.*

MINIMUM RECOMMENDED HEAT FLUX SENSOR MAINTENANCE			
	INTERVAL	SUBJECT	ACTION
1	1 week	data analysis	compare measured data to the maximum possible or maximum expected heater power, to other measurements from other redundant instruments and to data previously measured under identical circumstances. Look for any patterns and events that deviate from what is normal or expected. Compare to acceptance intervals.
2	6 months	inspection	inspect cable and wire quality, inspect mounting, inspect location of installation look for seasonal patterns in measurement data
3	2 years	lifetime assessment	judge if the instrument will be reliable for another 2 years, or if it should be replaced

5.2 Trouble shooting

Table 5.2.1 *Trouble shooting for HTR02 series.*

General	<p>Inspect the heater for any damage. Inspect the quality of mounting / installation. Inspect if the wires are properly attached to the data logger.</p> <p>Check the condition of the cable.</p> <p>Check the datalogger program in particular if the correct resistance is entered when not measuring according to the 4-wire method. HTR02 resistance and serial number are shown on the product certificate and on the sticker at the end of the cable.</p> <p>Check the electrical resistance of the heater between the wires of the heater. You may use a 4-wire connection. Use a multimeter at the 1k Ω range. Typical resistance should be around 120 Ω for model 50X50 and around 40 Ω for model 85X85 $\pm 10\%$. Infinite resistance indicates a broken circuit; zero or a lower than 1 Ω resistance indicates a short circuit.</p> <p>Check the heater resistance value in Ω on the product certificate.</p>
The heater measurements show unexpected variations	<p>Check the presence of strong sources of electromagnetic radiation (radar, radio).</p> <p>Check the condition of the heater cable.</p> <p>Check if the cable is not moving during the measurement.</p>

5.3 Calibration and checks in the field

The recommended calibration interval of heat flux sensors is 2 years.

Recalibration of field heat flux sensors is ideally done by the sensor manufacturer. You may also calibrate by yourself following chapter 2.4.

On-site field calibration is possible by comparison to a calibration reference sensor. Usually mounted side by side, alternatively mounted on top of the field sensor.

Hukseflux main recommendations for field calibrations are:

- 1) Compared to a calibration reference of the same brand and type as the field sensor
- 2) connect both to the same electronics, so that electronics errors (also offsets) are eliminated
- 3) mount all sensors on the same platform, so that they have the same body temperature
- 4) typical duration of test: > 24 h
- 5) typical heat flux used for comparison: 500 W/m²
- 6) correct for deviations of more than $\pm 20\%$. Lower deviations should be interpreted as acceptable and should not lead to a revised sensitivity

6 Appendices

6.1 EU declaration of conformity



We,

Hukseflux Thermal Sensors B.V., Delftechpark 31, Delft,
The Netherlands

hereby declare under our sole responsibility that:

Product model	HTR02 series, all models
Product type	heater for calibration and verification of performance of FHF-type heat flux sensors

is in conformity with the following directives:

2011/65/EU, EU 2015/863	The Restriction of Hazardous Substances Directive
-------------------------	---

This conformity is declared using the relevant sections and requirements of the following standards:

Hazardous substances	RoHS 2 and EU 215/863 amendment known as RoHS 3
----------------------	---

A handwritten signature in blue ink, appearing to be 'Eric Hoeksema', written over a faint circular stamp or watermark.

Eric HOEKSEMA
Director
Delft, 15 November 2022

